

# *Catalogue de pièces remanufacturés*

## *Reman Catalogue*



## Camion et Remorque

## Heavy Duty Truck and Trailer

[www.fleetspec.com](http://www.fleetspec.com)  
[info@fleetspec.com](mailto:info@fleetspec.com)

Sans frais / Toll Free: 1-888-350-FLEET (3533)

**Tel.: 1-514-956-0111      FAX: 1-514-956-0782**

5857 Chemin Saint-François, St-Laurent, Québec, H4S 1B6



Liste numérique des pièces / Numerical Index .....	A
Termes & conditions / Terms & Conditions .....	G
Politique pour les noyaux / Core Policy .....	H
Garantie / Warranty Policy .....	I
Référence d'interchange pour les soupapes à air / Air Valve Crossover Reference .....	J

## **Bendix**

Soupape d'échappement rapide / Quick Release Valves .....	1
Soupape de ratio et proportion / Ratio & Proportioning Valves .....	2
Soupape de contrôle à main / Hand Control Valves .....	3
Soupape à pied / Foot Operated Valves .....	10
Soupape de protection / Protection Valves .....	13
Soupape RV-1, SS-1 et SV-1 / Shut off & Synch. Valves .....	15
Soupape de retenue double, avec interrupteur / Dbl. Check & Stop Light ...	16
Soupape d'inversion / Inversion Valve .....	16
Soupape de relais / Relay Valves .....	17
Soupape de relais d'urgence / Relay Emergency Valves .....	20
Soupape de frein à ressort / Spring Brake Valves .....	21
Soupape à drainage & retention / Drain & Check Valves .....	23
Gouverneur / Governor .....	24
Assécheur d'air AD-IP/ AD-IP Air Dryer .....	24
Assécheur d'air AD-2/ AD-2 Air Dryer .....	25
Assécheur d'air AD-4/ AD-4 Air Dryer .....	26
Assécheur d'air AD-9/ AD-9 Air Dryer .....	27

<b>Berg</b> Soupape de relais / Relay Valves.....	28
---	----

<b>CR</b> Aftercooler .....	30
-----------------------------	----

<b>Fuller</b> Soupape pour le transmission / Transmission Valves .....	31
--	----

<b>Haldex ABS</b> .....	32
-------------------------	----

<b>Kelsey Hayes</b> Soupape pour le transmission / Transmission Valves.....	33
---	----

## **Midland**

Soupape d'échappement rapide, RG-2 / Quick Release, RG-2 .....	34
Soupape de remorque FF-2 / FF-2 Trailer Valve .....	35
Soupape à main / Hand Operated Valves .....	36
Soupape à pied / Foot Valves .....	38
Soupape de relais / Relay Valves .....	39
Soupape de frein à ressort / Spring Brake Valves .....	41
Soupape de protection / Tractor Protection Valves .....	42
Assécheur d'air / Air Dryer .....	44

**Sealco**

Soupape de contrôle / Control Valves .....	45
Soupape de relais d'urgence / Relay Emergency Valves .....	46
Soupape de relais / Relay Valves .....	47
Soupape de frein à ressort / Spring Brake Valves .....	49

**Shrader**

Soupape "Air-electrique" / Air-Electric Valve .....	50
---	----

**Wabco**

Truck, Tractor & Bus ABS .....	51
Trailer ABS .....	52

**Wagner**

Soupape de relais / Relay Valves .....	53
Soupape de frein à ressort / Spring Brake Valves .....	53

Numero de pièce Part Number	Description	Page
4005001010X	Wabco ABS ECU/Modulator Valve assy.	52
4005001020X	Wabco ABS ECU/Modulator Valve assy.	52
4005001030X	Wabco ABS ECU/Modulator Valve assy.	52
4721950050X	Wabco ABS Modulator Valve	51
4721950330X	Wabco ABS Modulator Valve	52
4721950820X	Wabco ABS Modulator Valve	51
4721950830X	Wabco ABS Modulator Valve	51
4725000120X	Wabco ABS ECU/Modulator Valve assy.	52
4725000210X	Wabco ABS ECU/Modulator Valve assy.	52
4725001030X	Wabco ABS "Entire Valve Package"	51
9730110220X	Wabco ABS Relay Valve	51
AD-200	Exhaust Adapter, for AD-2 Dryer	25
AD-400	Exhaust Adapter, for AD-4 Dryer	26
AL364040X	Haldex ABS Valve	TBA
B12343X	Berg Relay Valve	28
B12347X	Berg Relay Valve	28
B12350X	Berg Relay Valve	29
B12352X	Berg SERV Valve	29
B12360X	Berg Task Valve	28
B12361X	Berg Task Valve	28
F110139X	Sealco Relay Valve	47
F110147X	Sealco Spring Brake Control Valve	45
F110148X	Sealco Spring Brake Control Valve	45
F110170X	Sealco Spring Brake Control Valve	45
F110171X	Sealco Spring Brake Control Valve	45
F110191X	Sealco Spring Brake Control Valve	45
F110197X	Sealco Relay Valve	47
F110200X	Sealco Ratio Relay Emergency Valve	46
F110205X	Sealco Ratio Relay Emergency Valve	46
F110207X	Sealco Relay Valve	47
F110310X	Sealco Spring Brake Control Valve	45
F110315X	Sealco Spring Brake Control Valve	45
F110338X	Sealco Relay Emergency Valve	46
F110360X	Sealco LOV-2 Relay Valve	48
F110380X	Sealco LOV-4 Relay Valve	48
F110410X	Sealco Service Brake Relay Valve	48
F110415X	Sealco Service Brake Relay Valve	48
F110450X	Sealco Relay Valve	47
F110470X	Sealco Relay Emergency Valve	46
F110475X	Sealco Relay Emergency Valve	46
F110500X	Sealco Spring Brake Valve	49
F110570X	Sealco Control Line Valve	48
F110580X	Sealco Control Line Valve	48
F110700X	Use FS110800N	49
F110800X	Use FS110800N	49
F3100X	Sealco Mini Valve	45
F3800X	Sealco Spring Brake Exhaust Valve	49
F7101X	CR Brakemaster Aftercooler Model 62	30
F7103X	CR Brakemaster Aftercooler Model 68	30
F7129NAX	CR Bottom Cover, with Heater	30
F7129NASX	CR Bottom Cover, NO Heater	30

Numero de pièce Part Number	Description	Page
F9125X	Sealco Relay Valve	47
FA1000-5AX	Sealco Valve Cartridge	47
FA1000SX	Sealco Relay Emergency Valve	47
FA3546X	Fuller Transmission Shift Valve	31
FA3547X	Fuller Control Valve	31
FA4688X	Fuller Control Valve	31
FB065040X	Bendix AD-4 Air Dryer, 24V	26
FB065041X	Bendix AD-4 Air Dryer, 12V	26
FB065043X	Bendix AD-4 Cover, 24V	26
FB065044X	Bendix AD-4 Cover, 12V	26
FB065104X	Use FS065104N	18
FB065125X	Bendix R-12H Relay Valve	18
FB065145X	Use FS065145N	2
FB065146X	Use FS065146N	2
FB065154X	Bendix LQ-5 Bobtail Ratio	2
FB065206X	Bendix R-12 Relay Valve	18
FB065224X	Bendix AD-9 Air Dryer, 24V	27
FB065228X	Bendix AD-9 Extended Purge Volume, 12V	27
FB065229X	Bendix AD-9 Cover, 24V	27
FB065231X	Bendix AD-9 Cover, 12V	27
FB065313X	Bendix E-12 Dual Foot Valve	12
FB065314X	Bendix E-14 Dual Foot Valve	12
FB065317X	Bendix E-14 Dual Foot Valve	12
FB065395X	Bendix E-14 Dual Foot Valve	12
FB065437X	Use FS065437N	21
FB065438X	Bendix SR-5 Spring Brake Valve	21
FB065439X	Use FS065439N	21
FB065440X	Bendix SR-5 Spring Brake Valve	21
FB065451X	Bendix RE-6NC Relay Emergency Valve	20
FB065523X	Bendix MV-3 Control Module	7
FB065643X	Bendix PP-DC Control Valve	5
FB065661X	Bendix PP-DC Control Valve	5
FB065690X	Bendix PP-DC Control Valve	5
FB101100X	Bendix E-10 Dual Foot Valve	12
FB101112X	Bendix SR-4 Spring Brake Valve	22
FB101437X	Bendix MV-2 Control Module	6
FB101450X	Bendix TR-3 Inversion Valve	16
FB101479X	Bendix PP-7 Control Valve	4
FB101569X	Bendix MV-2 Spool Assembly (red)	6
FB101570X	Bendix MV-2 Spool Assembly (yel)	6
FB101622X	Bendix SR-4 Spring Brake Valve	22
FB101818X	Bendix E-7 Dual Foot Valve	11
FB101900X	Bendix AD-2 Desiccant Cartridge	25
FB102388X	Bendix TC-7 TrailerControl Valve	9
FB102626X	Use FS102626N	18
FB102761X	Bendix SR-2 Spring Brake Valve	21
FB103009X	Use FS103009N	18
FB103010X	Use FS103010N	19
FB103028X	Use FS103028N	19
FB103061X	Bendix SR-2 Spring Brake Valve	21
FB103081X	Use FS103081N	17
FB103976X	Bendix PR-4 Pressure Protection Valve	14

Numero de pièce Part Number	Description	Page
FB104308X	Bendix E-6 Dual Circuit Foot Valve	11
FB104358X	Bendix AD-4 Desiccant Cartridge	26
FB104598X	Bendix BP-1 Proportioning	2
FB106284X	Bendix BP-1 Proportioning	2
FB106941X	Bendix TP-5 Protection Valve	14
FB107539X	Bendix SR-4 Spring Brake Valve	22
FB107794X	Bendix AD-9 Desiccant Cartridge	27
FB107800X	Bendix AD-9 Check Valve Ass'y	27
FB108076X	Bendix SR-4 Spring Brake Valve	22
FB109264X	Use FS065476N	19
FB109477X	Bendix AD-IP Dryer, 12V	24
FB109478X	Bendix AD-IP Dryer, 24V	24
FB109493X	Bendix AD-IP Desiccant Cartridge	24
FB109685HX	Bendix AD-9 for Holset Compressor	27
FB109685X	Bendix AD-9 Dryer, 12V	27
FB225892X	Bendix TW-3 Control Valve	8
FB227661X	Bendix TP-2 Tractor Protection Valve	13
FB227672X	Bendix TP-2 Tractor Protection Valve	13
FB228520X	Bendix DS-1 Dbl Check Vlv/Stop Light Sw.	16
FB229434X	Bendix RE-4 Relay Valve	20
FB229493X	Bendix DS-1 Dbl Check Vlv/Stop Light Sw.	16
FB229505X	Use FS229505N	1
FB229507X	Use FS229507N	1
FB229509X	Use FS229509N	1
FB229635X	Use FS229635N	8
FB229859X	Use FS229859N	1
FB229860X	Use FS229860N	1
FB276270X	Bendix TC-2 Trailer Control Valve	9
FB276462X	Bendix PP-2 Control Valve	3
FB276566X	Use FS276566N	3
FB276567X	Use FS276567N	3
FB276635X	Use FS276635N	8
FB277144X	Bendix RV-1 Press. Reducing Valve	15
FB277147X	Use FS277147N	14
FB277148X	Use FS277148N	14
FB277340X	Bendix TR-2 Inversion Valve	16
FB277863X	Use FS277863N	10
FB278614X	Use FS278614N	23
FB278824X	Bendix SS-1 Shut Off Valve	15
FB278825X	Use FS278825N	15
FB278998X	Bendix E-3 Foot Valve	10
FB279000X	Use FS279000N	13
FB279180X	Use FS279180N	17
FB279692X	Bendix TP-3 Tractor Protection Valve	13
FB279750X	Bendix E-4 Dual Foot Valve	10
FB279787X	Bendix PP-3 Control Valve	3
FB279950X	Bendix E-5 Foot Valve	10
FB279952X	Bendix R-6 Relay Valve	17
FB280454X	Bendix PP-2 Control Valve	3
FB280758X	Bendix TR-3 Inversion Valve	16
FB280904X	Bendix TH-3 Control Valve	8
FB280905X	Bendix TW-2 Control Valve	8

Numero de pièce Part Number	Description	Page
FB281262X	Bendix SV-1 Synchronizing Valve	15
FB281318X	Bendix TR-3 Inversion Valve	16
FB281459X	Bendix TR-3 Inversion Valve	16
FB281587X	Bendix PP-1 Control Valve	3
FB281860X	Bendix RE-6 Relay Emergency Valve	20
FB281865X	Use FS281865N	20
FB281923X	Use FS281923N	23
FB282499X	Bendix PP-1 Control Valve	3
FB283700X	Bendix SV-1 Synchronizing Valve	15
FB283940X	Use FS283940N	17
FB284358X	Use FS284358N	24
FB284412X	Use FS284412N	23
FB284760X	Bendix E-7 Foot Valve	11
FB284818X	Bendix DV-2 Drain Valve, Heated 24V	23
FB286171X	Bendix E-6 Dual Circuit Foot Valve	11
FB286364X	Use FS286364N	21
FB286370X	Use FS286370N	17
FB286460X	Use FS286460N	14
FB286500X	Use FS286500N	14
FB286774X	Bendix E-7 Dual Foot Valve	11
FB286873X	Bendix AD-2 Purge Valve	25
FB286875X	Bendix AD-2 Cover, 12V	25
FB286876X	Bendix AD-2 Cover, 24V	25
FB286934X	Bendix AD-2 Air Dryer, 12V	25
FB286936X	Bendix AD-2 Air Dryer, 24V	25
FB287114X	Bendix R-8P Pilot Relay Valve	17
FB287238X	Bendix PP-8 Control Valve	4
FB287240X	Bendix PP-8 Control Valve	4
FB287376X	Bendix SR-2 Spring Brake Valve	21
FB287411X	Bendix E-7 Dual Foot Valve	11
FB287417X	Bendix PP-1 Control Valve	3
FB287418X	Bendix PP-8 Control Valve	4
FB287600X	Bendix PP-1 Control Valve	3
FB287637X	Bendix PP-1 Control Valve	3
FB288239X	Use FS288239N	4
FB288240X	Bendix PP-7 Control Valve	4
FB288241X	Bendix PP-7 Control Valve	4
FB288242X	Bendix PP-7 Control Valve	4
FB288301X	Bendix TP-4 Tractor Valve (Ford L)	13
FB288323X	Bendix PR-4 Pressure Protection Valve	14
FB288497X	Bendix SR-2 Spring Brake Valve	21
FB288586X	Bendix TR-3 Inversion Valve	16
FB288605X	Bendix TP-5 Tractor Protection Valve	14
FB288746X	Bendix PP-3 Control Valve	3
FB289144X	Bendix LQ-4 Ratio Valve	2
FB289182X	Bendix QR-1C Quick Release Valve	1
FB289253X	Bendix TP-5 Tractor Valve	14
FB289259X	Bendix PP-8 Control Valve	4
FB289477X	Bendix PP-3 Control Valve	3
FB289512X	Bendix PP-3 Control Valve	3
FB289714X	Use FS289714N	1



Numero de pièce Part Number	Description	Page
FB5000359X	Bendix PP-DC Control Valve	5
FB5001455X	Bendix TP-3DC Protection Valve	13
FB5004341X	Bendix AD-9 Purge Valve Assy, 12V	27
FB5004342X	Bendix AD-9 Purge Valve Assy, 24V	27
FB5005878X	Bendix MV-3 Control Module	7
FB800004X	Bendix PP-DC Control Valve	5
FB800034X	Bendix PP-DC Control Valve	5
FB800257X	Bendix MV-3 Control Module	7
FB800258X	Bendix MV-3 Control Module	7
FB800259X	Bendix MV-3 Control Module	7
FB800260X	Bendix MV-3 Control Module	7
FB800353X	Bendix MV-3 Control Module	7
FB800404X	Bendix AD-IP Purge Valve Assy.	24
FB800515X	Bendix MV-3 Control Module	7
FB800516X	Bendix MV-3 Control Module	7
FB800517X	Bendix MV-3 Control Module	7
FB800518X	Bendix MV-3 Control Module	7
FB800519X	Bendix MV-3 Control Module	7
FB800521X	Bendix MV-3 Control Module	7
FB800523X	Bendix MV-3 Control Module	7
FB800530X	Bendix MV-3 Control Module	7
FB800573X	Bendix MV-3 Control Module	7
FB800584X	Bendix MV-3 Control Module	7
FB800629X	Bendix E-8P Dual Foot Valve	11
FKN20080X	Midland Double Flipper Valve	36
FKN20090X	Midland Double Flipper Valve	36
FKN20110X	Midland Double Flipper Valve	36
FKN20541X	Midland Trailer Brake Control Valve	37
FKN20551X	Midland Trailer Brake Control Valve	37
FKN20552X	Midland Trailer Brake Control Valve	37
FKN20561X	Midland Trailer Brake Control Valve	37
FKN20562X	Midland Trailer Brake Control Valve	37
FKN20601X	Midland Manifold Dash Valve	36
FKN20606X	Midland Manifold Dash Valve	36
FKN20612X	Midland Manifold Dash Valve	36
FKN20615X	Midland Manifold Dash Valve	36
FKN22100X	Midland Single Circuit Foot Valve	38
FKN22140X	Midland Dual Circuit Foot Valve	38
FKN26000X	Midland RT-4 Multifunction Trailer Valve	41
FKN26010X	Midland RT-4 Multifunction Trailer Valve	41
FKN28030X	Midland Inversion Valve	41
FKN28060X	Use FSKN28060N	39
FKN28061X	Midland Relay Valve	39
FKN28065X	Midland Relay Valve	40
FKN28071X	Midland Relay Valve	40
FKN28080X	Midland Relay Valve	39
FKN28130X	Midland Relay Valve	39
FKN28132X	Midland Relay Valve	39
FKN28140X	Midland Relay Valve	40
FKN28500X	Use FSKN28500N	34
FKN28510X	Use FSKN28510N	34

[illegible]

## TERMES ET CONDITIONS

### PROCÉDURE DE COMMANDE :

Vos commandes peuvent être effectuées par la poste, le téléphone ou le fax :

Adresse postale :  
Téléphone :  
Fax :

FleetSpec, 5857 Chemin Saint-François, St-Laurent, Québec, H4S 1B6  
(514) 956-0111 ou sans frais : 1-888-350-FLEET (3533)  
(514) 956-0782

### TERMES:

Net 30 jours

### CONDITIONS :

- Des intérêts sont imputables pour tout compte en souffrance.
- Tout solde impayé selon le délai entraînera le paiement sur livraison (C.O.D.) ou paiement à l'avance de toute nouvelle commande.
- Tout envoi de produits est basé sur le prix établi à Montréal.
- Les frais de transport pour toute commande excédant 3,000.00 \$, mais excluant les prix des noyaux, sont défrayés par FleetSpec.
- Les noyaux sont payables, selon les termes spécifier ci-haut.
- Tout produit en attente de réception du fournisseur sera ajouté à votre prochain envoi, sauf avis contraire.

**TRANSPORT DES NOYAUX : Les clients doivent retourner les noyaux,  
à leurs frais, à l'adresse suivante :**

**FleetSpec, 684 Martel,  
St-Brigide d'Iberville,  
Québec, J0J 1X0**

## TERMS & CONDITIONS

### ORDERING PROCEDURES :

Orders can be placed by mail, telephone or fax

Mailing address:  
Telephone :  
Fax :

FleetSpec, 5857 Chemin Saint-François, St-Laurent, Québec, H4S 1B6  
(514) 956-0111 or toll free : 1-888-350-FLEET (3533)  
(514) 956-0782

### TERMS :

Net 30 days

### CONDITIONS:-

- A late payment charge will be added to all past due invoices
- Any unpaid account within the stated terms is subject to a C.O.D. or C.I.A. status.
- All shipments are F.O.B. Montréal
- Prepaid freight on orders of \$3,000.00 or more in value (excluding cores)
- Cores are payable in accordance with the above terms
- Back order items will be added to your next order, unless specified otherwise

**CORE FREIGHT : All customers will return cores (freight prepaid)  
to the following address :**

**FleetSpec, 684 Martel,  
St-Brigide d'Iberville,  
Québec, J0J 1X0**

## POLITIQUE POUR LES NOYAUX

Tout client se verra octroyer une période d'un an, à partir de la date de la facturation, pour retourner les noyaux afin d'obtenir le crédit applicable. Tout produit contenu dans la banque de noyaux sera automatiquement effacé de la banque s'il n'est pas retourné à l'intérieur de la période de douze (12) mois.

Les noyaux retournés à FleetSpec, mais ne faisant pas l'objet d'un crédit, seront placés dans la banque de noyaux du client pour une période d'un (1) an. Après cette période, les noyaux contenus dans la banque et non utilisés lors d'achat subséquente deviendront la propriété de FleetSpec.

Basé sur la politique « item par item », le crédit de noyau sera appliqué en fonction de tout achat préalablement effectué.

FleetSpec peut également être intéressé par l'achat de certains types de noyaux ne figurant pas dans la banque de noyau du client, et pour lesquels un crédit ne peut être émis. Cet achat s'effectuera uniquement en fonction des besoins de FleetSpec.

Les noyaux reçus endommagés ou avec pièces manquantes seront susceptibles de frais comme suit:

- Une pièce manquante ou défectueuse : 50% de la valeur reçue
- Plus d'une pièce manquante ou défectueuse : Aucune valeur

La valeur monétaire de tout noyau ainsi que toute charge additionnelle se négocient au moment de l'entente de vente.

Les noyaux répertoriés « endommagés » à la suite d'une inondation, d'un incendie, de surchauffe ou d'abandon dans des dépotoirs n'ont aucune valeur négociable.

## CORE POLICIES

Each customer has one year from the purchase date of the finished product to return the core in order to receive the appropriate credit. Any item in the customer's core bank will then be deleted if it is not returned before the end of the twelve (12) month period.

Cores returned to FleetSpec, which are not eligible for core return credit, will be placed in a core bank for up to one (1) year. Cores remaining in that bank after a one (1) year period without a corresponding purchase will become the sole property of FleetSpec.

Based on an «item by item» policy, the core credit can be granted against the item previously purchased.

FleetSpec may also be interested in purchasing certain cores for which the customer is not entitled to a credit, following the core bank policy. Offers to purchase such cores will be on an «as needed» basis.

Cores with damaged or missing components are subject to the following percentage charge backs :

- One part damaged or missing : deduct 50% of full core value
- Cores with more than one part damaged or missing : no value

The value of any core, as well as any additional charges, are determined at the point of sale.

Cores that are classified as flood, fire, heat damaged or « junkyard cores » have no value.

## GARANTIE

FleetSpec garantit que tous ses produits remanufacturés, achetés ou distribués sont sans défaut tant au niveau du matériel que de l'assemblage et ce, en fonction d'un usage normal. La politique générale de garantie de la série « FS » de FleetSpec couvre une période de douze (12) mois à compter de la date de facturation, à l'exception des valves (remanufacturées) où la garantie est de douze (12) mois à compter de la date du sceau d'identification attaché à la valve.

Toute marchandise sous garantie doit nous être retournée, <<à vos frais>>, lors de votre prochain envoi de noyaux à l'adresse suivante : FleetSpec, a/s Avant-Garde, 684 Martel, St-Brigide d'Iberville, Québec, JOJ 1X0.

FleetSpec, à sa discrétion, réparera, remplacera sans frais, créditera les composantes défectueuses ou remplacera les composantes défectueuses par des pièces équivalentes, sans frais supplémentaires.

La garantie sur nos produits est annulée si :

- Les pièces ne sont pas installées selon nos spécifications
- Les pièces subissent des altérations et/ou modifications non conformes à nos spécifications sans notre approbation préalable.

Si un produit ne comporte aucune garantie ou fonctionne normalement, les options suivantes sont envisageables :

- Le produit peut vous être retourné, à vos frais
- FleetSpec en dispose, à sa convenance

La garantie s'applique uniquement au premier acheteur utilisateur du produit et n'est pas transférable.

La garantie offerte par FleetSpec ne peut être modifiée ou révisée par un employé, agent ou représentant.

La garantie ne couvre pas les frais d'installation, la main-d'œuvre, le transport, la perte de temps et tous autres frais connexes.

Le produit défectueux, couvert par la garantie, sera soit remplacé ou crédité par FleetSpec, à notre discrétion.

## WARRANTY

FleetSpec warrants products it manufactured or supplied to be free from defects in material and workmanship under normal use and service. The overall warranty policy on the FleetSpec « FS » numbers is for twelve (12) months from the date of invoice, except for valves (remanufactured) where the warranty is for a twelve (12) months period, from the date of the identification tag attached to the valve.

All warranty returns must be shipped, <<Pre-Paid>>, with the next scheduled core return shipment to the following address : FleetSpec, c/o Avant-Garde, 684 Martel, St-Brigide d'Iberville, Québec, JOJ 1X0.

FleetSpec will, at our option, either repair, replace without charge, or give credit for components or parts shown to be defective or replace those defective parts by equivalent ones.

The warranty on our products is void when :

- Parts are not installed according to our specifications.
- Parts are altered or changed from originals specifications without our knowledge and consent.

If a product is determined to be non-warrantable or is found to function normally, the following options are available :

- The product may be returned to you freight « collect »
- FleetSpec can dispose of the part(s) at its warehouse

The warranty only applies to the first user purchaser of the product.

The warranty is offered by FleetSpec and therefore no employee, agent, salesman or other person has the authority to offer or make any other warranty.

The warranty does not cover charges for installation, labor, travel, consequential damages, loss of time or other incidentals.

Products found to be defective under the warranty will be rectified by credit or replacement of the part, at FleetSpec's discretion.

### Bendix à/to Bendix

PART #	FleetSpec Replacement
R-1	FB103009X
R-1C	FB103009X
R-5	FB102626X, FB103009X
R-6	FB102626X, FB103009X
R-8	FB103010X
R-12	FB102626X
R-12H	FB103009X
R-14	FB103028X
R-14H	FB103010X
RE-1C	FB229434X
RE-4	FB229434X
RE-6	FB281865X
SR-1	FB286364X
SR-2	FB287376X
SR-4	FB101112X

### Berg à/to Bendix

PART #	FleetSpec Replacement
B12340X	FB103009X
B12341X	FB103009X
B12342X	FB102626X, FB103009X
B12344X	FB102626X, FB103009X
B12345X	FB102626X, FB103009X
B12346X	FB102626X, FB103009X
B12352X	FB101112X & FB102626X
B12360X	FB101112X, FB102626X

### Kelsey Hayes à/to Bendix

PART #	FleetSpec Replacement
KH5468X	FB103009X
KH5470X	FB102626X

### Midland à/to Bendix

PART #	FleetSpec Replacement
KN20541X	FB101112X, FB101622X
KN28000X	FB103009X
KN28010X	FB102626X, FB103009X
KN28011X	FB102626X, FB103009X

### Midland à/to Bendix (cont'd)

PART #	FleetSpec Replacement
KN28060X	FB103009X
KN28061X	FB103009X
KN28071X	FB103010X
KN28132X	FB103009X
KN28140X	FB103010X

### Sealco à/to Bendix

PART #	FleetSpec Replacement
S9125X	FB102626X, FB103009X
SA1100X	FB102626X

### Wagner à/to Bendix

PART #	FleetSpec Replacement
WA104001X	FB101112X, FB101622X
WA104003X	FB101112X, FB101622X
WA104010X	FB101112X, FB101622X
WA78882X	FB102626X, FB103009X
WA78887X	FB102626X, FB103009X
WA86473X	FB102626X
WA86477X	FB102626X
WA88802X	FB101112X, FB101622X
WA88812X	FB101112X, FB101622X
WA98730X	FB101112X, FB101622X
WA98731X	FB101112X, FB101622X
WA98732X	FB101112X, FB101622X

### Bendix à/to Midland

PART #	FleetSpec Replacement
BW065104X	WA103600X
BW101100X	FKN22150X
BW101112X	FKN26000X
BW101622X	FKN26000X
BW102626X	WA86477X
BW103009X	FKN28140X
BW103010X	FKN28071X
BW103028X	WA86477X
BW227661X	FKN34070X
BW227672X	FKN34070X
BW229434X	FKN30300X

### Bendix à/to Midland (cont'd)

<u>PART #</u>	<u>FleetSpec Replacement</u>
BW229467X	FKN28060X
BW229500X	FKN22100X
BW229501X	FKN22100X
BW229505X	FKN32030X
BW229507X	FKN32030X
BW229509X	FKN32030X
BW277144X	FKN31060X
BW277147X	FKN31000X
BW277148X	FKN31010X
BW277214X	FKN31060X
BW277226X	FKN31000X
BW277227X	FKN31010X
BW277446X	FKN30300X
BW277863X	FKN22100X
BW278426X	FKN31060X
BW278614X	FKN25060X
BW278615X	FKN25060X
BW278898X	FKN22100X
BW279000X	FKN34060X
BW279180X	FKN28140X
BW279962X	FKN34060X
BW280243X	FKN28132X
BW280651X	WA103600X
BW281860X	FKN30400X
BW281865X	FKN30300X
BW281923X	FKN24000X
BW283940X	FKN28140X
BW284358X	FKN18534X
BW284795X	FKN24001X
BW286171X	FKN22140X
BW286364X	FKN28030X
BW286370X	FKN28071X
BW286371X	FKN28071X
BW286500X	FKN31010X
BW287224X	FKN28071X
BW287260X	FKN28071X
BW287376X	B12360X
BW288063X	FKN28030X
BW288323X	FKN31010X
BW288369X	FKN28071X
BW288417X	FKN32030X
BW289182X	FKN32040X
BW289714X	FKN32040X
BW229501X	FKN22100X

### Berg à/to Midland

<u>PART #</u>	<u>FleetSpec Replacement</u>
11661	WA103600X
11675	FKN30300X
B12343X	WA86477X
B12345X	WA103600X
B12346X	FKN28500X
B12350X	FKN30400X
B12360X	FKN26000X

### Midland à/to Midland

<u>PART #</u>	<u>FleetSpec Replacement</u>
B12360X	FKN26000X
KN28150X	FKN26000X
KN28160X	FKN28500X
KN30010X	FKN30300X

### Bendix à/to Sealco

<u>PART #</u>	<u>FleetSpec Replacement</u>
BW102626X	F110415X, F110416X
BW103009X	F110415X, F110416X
BW103109X	F110415X
BW228500X	F110200X, F110268X
BW229467X	F110416X
BW279180X	F110416X
BW281865X	F110170X
BW286171X	F110400X
BW287114X	F110370X
BW287375X	F110170X
BW287376X	F110170X
R-12	F110416X
R-14	F110416X
R-5	F110416X
R-6	F110416X
R-8	F110416X
RE-4	FA1000X, F110268X
RE-6	F110205X
SR-2	F110170X

### Berg à/to Sealco

<u>PART #</u>	<b>FleetSpec Replacement</b>
11675	FA1000X, F110268X, F110470X
B12341X	F110410X
B12343X	F110415X
B12345X	F110415X
B12346X	F110410X
B12360X	F110170X
B12361X	F110170X
WA99036X	F110200X

### Sealco à/to Midland

<u>PART #</u>	<b>FleetSpec Replacement</b>
S3100X	FKN28500X
S9125X	FKN28500X
S110139X	WA103600X
S110147X	FKN26000X
S110171X	FKN26000X
S110180X	FKN26000X
S110190X	FKN26000X
S110200X	FKN30300X
S110205X	FKN30400X
S110230X	FKN26000X
SA1000X	FKN30300X
SA1100X	WA103600X

### Wagner à/to Midland

<u>PART #</u>	<b>FleetSpec Replacement</b>
WA104001X	FKN26000X
WA104002X	FKN26000X
WA104003X	FKN26000X
WA104010X	FKN26010X
WA37411X	FKN30300X
WA46229X	FKN30100X
WA71890X	FKN30300X
WA71891X	FKN30200X
WA78880X	FKN28500X
WA78882X	FKN28510X
WA78886X	FKN28500X
WA78887X	FKN28520X
WA78889X	FKN28510X
WA80070X	FKN28500X

### Wagner à/to Midland (cont'd)

<u>PART #</u>	<b>FleetSpec Replacement</b>
WA83335X	FKN26000X, B12360X
WA83336X	FKN26000X, B12360X
WA86310X	FKN28500X
WA86311X	FKN28500X
WA86313X	FKN28510X
WA86314X	FKN28510X
WA86318X	FKN28510X
WA88802X	FKN26000X
WA88812X	FKN26000X
WA98730X	FKN26000X
WA99036X	FKN30400X

### Kelsey Hayes à/to Midland

<u>PART #</u>	<b>FleetSpec Replacement</b>
KH5454X	WA103600X

### Midland à/to Sealco

<u>PART #</u>	<b>FleetSpec Replacement</b>
WA30010X	F110200X
KN22140X	F110400X
KN22150X	F110400X
KN26000X	F110191X
KN26010X	F110191X
KN28060X	F110416X
KN28140X	F110416X
KN28300X	F110370X
KN28500X	F110416X
KN28510X	F110410X, F110416X
KN30000X	FA1000X
KN30100X	FA1000X, F110200X
KN30200X	F110267X, F110338X
KN30300X	FA1000X, F110200X
KN30400X	FA1000X, F110200X
KN39011X	F110460X
RG-2	F110410X
RT-4	F110191X



## QR-1

### Quick Release

**FS229859N**

3/8" PT Sup.  
3/8" PT Del.

**FS229860N**

1/2" PT Sup.  
3/8" PT Del.



Disponible neuve seulement.  
As we are no longer rebuilding this valve, it is available "new" only.

## QR-1C

### Anti-Compounding Quick Release

**FB289182X**

1/4" PT Sup.  
1/4" PT Del.

**FS289714N**

1/4" PT Sup.  
3/8" PT Del.

Disponible neuve seulement.  
As we are no longer rebuilding this  
valve, it is available "new" only.



Crack @ 1 PSI

## LQ-2

### Limiting and Quick Release


No. pièce Part No.	A PT	B PT
FS229505N	3/8	3/8
FS229507N	1/2	1/4
FS229509N	3/8	1/4



Disponible neuve seulement.  
As we are no longer rebuilding this valve, it is available "new" only.

## LQ-4


### Front Axle Ratio



**FB289144X**

Nominal hold off pressure: 4  
Nominal equalizing pressure: 60

### Bobtail Ratio




**FB065154X**

#### "IMPORTANT"

Ne remplace pas ce LQ-5 avec un BP-1 d'avant ou d'arrière  
Do not replace this LQ-5 with Front or Rear BP-1

## BP-1

### Air Brake Proportioning



**FB104598X** (Pont en avant / Front axle)

Nominal Holdoff: 4 PSI; Nominal Equalizing: 50 PSI

**FB106284X** (Pont en arrière / Rear axle)


Nominal Holdoff: 8 PSI; Nominal Equalizing: 105 PSI

#### "IMPORTANT"

L'application pour le BP-1 en avant et en arrière n'est pas interchangeable.  
The front & rear applications on the BP-1 are not interchangeable.

### Bobtail Proportioning

## BP-R1



**FS065145N** Crack @ 4 PSI

**FS065146N** Crack @ 5.5 PSI


Disponible neuve seulement.

As we are no longer rebuilding this valve, it is available "new" only.

## PP-1

### Push & Pull Control

No. pièce Part No.	Del. "A"	Relache Release	Shaft
FS276566N	1/8"	20 PSI	3/8"
FS276567N	1/8"	40 PSI	3/8"
FB281587X	1/8"	40 PSI	1/2", 1/4-20 Thd.
FB282499X	1/4"	40 PSI	3/8"
FB287417X	1/4"	30 PSI	3/8"
FB287600X	1/4"	40 PSI	3/8"
FB287637X	1/8"	Non-auto	1/4"




Bouton et écrou pas incluse.  
Button and nut not included.

## PP-2

### Push & Pull Control

No. pièce Part No.	Relache Release	Shaft
FB276462X	40 Psi	3/8"
FB280454X	40 Psi	1/4-20 Thd.




Bouton et écrou pas incluse.  
Button and nut not included.

## PP-3

### Push & Pull Control, with Automatic Tripper

No. pièce Part No.	"A"	Shaft
FB279787X	Bouché Plugged	1/4-20 Thd.
FB288746X	Bouché Plugged	3/8"
FB289477X	1/8" P.T.	3/8"
FB289512X	1/8" P.T.	1/4-20 Thd.




Bouton et écrou pas incluse.  
Button and nut not included.

\* Tripper Exhausts at 30 PSI & Charges Above 50 PSI. Plunger trips at 40 PSI and Charges Manually

## Trailer Supply Valve

**PP-7**



Bouton et écrou pas incluse.  
Button and nut not included.

No. pièce Part No.	Relache Release	Shaft
FB101479X <sup>(2)</sup>	40 PSI	3/8"
FS288239N <sup>(3)</sup>	40 PSI	3/8"
FB288240X	40 PSI	1/2", 1/4-20 Thd.
FB288241X <sup>(1)</sup>	40 PSI	5/16"
FB288242X	40 PSI	1/2", 1/4-20 Thd.

<sup>(1)</sup> Exhaust port has 1/4" PT


<sup>(2)</sup> Index notch in Panel Flange

<sup>(3)</sup> Disponible neuve seulement.

As we are no longer rebuilding this  
valve, it is available "new" only.

## Manually Operated Control Valve

**PP-8**




Bouton et écrou pas incluse.  
Button and nut not included.

No. pièce Part No.	Del. "B"
FB287238X	1/8" PT
FB287240X <sup>(1)</sup>	1/8" PT
FB287418X	1/4" PT
FB289259X <sup>(1)</sup>	1/8" PT

<sup>(1)</sup> Remote mount 1/4"  
female thread in shaft.

## PP-DC

### Park Control Valve



\*\* Buttons for illustrative purposes only. Not included with valve.

No. pièce Part No.	Fig	Trous d'attachement Mtg. Hole	Connection Port Fittings
FB065643X	2	.27" Dia.	Push-to-Connect
FB065661X	1	1/4"- 20 THD	Push-to-Connect
FB065690X	1	.27" Dia.	Push-to-Connect
FB800004X	2	#10-24 THD	Push-to-Connect
FB800034X	2	.27" Dia.	1/4" PT
FB5000359X	2	1/4"- 20 THD	1/4" PT

No. pièce original Original Part #	à remplacer par Replaced By
BW109636	FB065643X
BW109795	FB065661X
BW109880	FB065661X
BW109881	FB065690X
BW5000054	FB800004X
BW5000360	FB800034X

Fig. 1





Fig. 2



**Control Module**

**MV-2**



**FB101437X**

**Spool Assemblies**

"A"  
Rouge / Red




FB101569X

"B"  
Jaune / Yellow



FB101570X



Tous les orifices(6) 1/4" PT / All ports(6) 1/4" PT

## MV-3

### Control Module

No. Pièce Part #	Fig	Trous d'attachement Mtg. Hole	Aux. port	Exh. port	Del. Ports
FB065523X	1	.27" Dia.	Non	Nipple	Push-to-Connect
FB5005878X	1	#10-24	Non	1/4" PT female	1/4" PT
FB800257X	1	.27" Dia.	Non	Push-to-Connect	Push-to-Connect
FB800258X	2	M6 x 1-6H	Non	Push-to-Connect	Push-to-Connect
FB800259X	1	1/4"-20 THD.	Non	Push-to-Connect	Push-to-Connect
FB800260X	1	M5 x 8.0 -6H	Non	Push-to-Connect	Push-to-Connect
FB800353X	1	#10-24	Non	Push-to-Connect	Push-to-Connect
FB800515X	1	M6 x 1-6H	Non	Nipple	1/4" PT
FB800516X	1	.27" Dia.	Non	Nipple	1/4" PT
FB800517X	3	M6 x 1-6H	Non	1/8" PT male	1/4" PT
FB800518X	1	.27" Dia.	1/8" PT	Nipple	1/4" PT
FB800519X	1	1/4"-20 THD.	Non	1/4" PT female	1/4" PT
FB800521X	2	1/4"-20 THD.	Non	Nipple	1/4" PT
FB800523X	1	#10-24	Non	Nipple	1/4" PT
FB800530X	1	1/4"-20 THD.	Non	Nipple	1/4" PT
FB800573X	1	1/4"-20 THD.	Non	1/8" PT male	1/4" PT
FB800584X	1	M6 x 1-6H	1/8" PT	Nipple	1/4" PT

No. pièce original Original Part #	à remplacer par Replaced By
BW065156X	FB800515X
BW065157X	FB800516X
BW065159X	FB800517X
BW065160X	FB800518X
BW065186X	FB800573X
BW065187X	FB800573X
BW065192X	FB800521X
BW065208X	FB800584X
BW065248X	FB800523X
BW065379X	FB800517X
BW106981X	FB800584X
BW109935X	FB065523X
BW5000378X	FB800259X
BW5001230X	FB800516X
BW5002695X	FB800258X
BW5002714X	FB800260X
BW5002716X	FB800259X
BW5003682X	FB800353X
BW5005077X	FB800516X
BW800036X	FB800519X
BW800529X	FB800259X



Fig. 1




Fig. 3






Fig. 2



## TW-1

### Lever Operated Control Valve



**FS229635N**


Disponible neuve seulement.  
As we are no longer rebuilding this valve, it is available "new" only.

Usage: Pour les freins de stationnement & urgence.  
Use: To control parking & emergency brakes.

### Lever Operated Control Valve

## TH-3

## TW-2



TH-3 (Lever à 3 position / 3 lever positions)

**FB280904X**

TW-2 (Lever à 2 position / 2 lever positions)

**FB280905X**

Usage: Pour les freins de stationnement & urgence.  
Use: To control parking & emergency brakes.

## TW-3

### Lever Operated Control Valve




**FB225892X**

Usage: Pour les freins de stationnement & urgence.  
Avoir un peu plus capacité que le TW-1.  
Use: To control parking & emergency brakes.  
Has slightly greater capacity than TW-1.

### Push Button Control Valve

## TW-4



**FS276635N**

Disponible neuve seulement.  
As we are no longer rebuilding this valve, it is available "new" only.

Usage: Utilisé avec un système de démarreur à air.  
Use: Commonly used with air starter systems.

Bouton pas incluse.  
Button not included.



**TC-2**

**Trailer Control Valve**

**FB276270X**




Support et poignée pas incluse.  
Mounting bracket and handle not included.

**TC-7**

**Trailer Control Valve**

**FB102388X**



Support et poignée pas incluse.  
Mounting bracket and handle not included.

### Single Circuit Foot Valve

**E-3**



**FS277863N**


Disponible neuve seulement.  
As we are no longer rebuilding this valve, it is available "new" only.

\* **FB278998X**

Pédale pas incluse.  
Treadle and mounting brackets not included.

### Dual Circuit Foot Valve

**E-4**




**FB279750X**

Pédale pas incluse.  
Treadle and mounting brackets not included.

### Single Circuit Foot Valve

**E-5**



**FB279950X**

Orifice Del.  
Del. Ports

Orifice Sup.  
Sup. Ports

D1 1/4" PT (2)  
D2 3/8" PT (1)  
D3 1/2" PT (1)

S1 1/4" PT (5)  
S2 1/2" PT (1)

Pédale pas incluse.  
Treadle and mounting brackets not included.


## E-6

### Dual Circuit Foot Valve

### Ford flange mount

\* Disponible neuve seulement.  
As we are no longer rebuilding this  
valve, it is available "new" only.

\*



\* **FS286171N**



**FB104308X**

Pédale pas incluse. Treadle and mounting brackets not included.

## E-7

### Dual Circuit Foot Valve

No. pièce Part No.	Del. gauche Left Del.	Sup. gauche Left Sup.	Del. droit Right Del.	Sup. droit Right Sup.	Exh.
FB101818X	3/8" PT	1/4" PT	3/8" PT	1/4" PT	Diaphragm
FB284760X	-	-	-	1/4" PT	Diaphragm
FB286774X	1/4" PT	1/4" PT	1/4" PT	1/4" PT	1/2" PT
FB287411X	3/8" PT	3/8" PT	1/4" PT	1/4" PT	1/2" PT




Pédale pas incluse.  
Treadle and mounting brackets not included.

## E-8P

### Dual Circuit Foot Valve


**FB800629X**



Pédale pas incluse.  
Treadle and mounting brackets not included.

**Dual Circuit Foot Valve**

**E-10**




**FB101100X**

(Orifices 3/8" PT)  
(all ports 3/8" PT)

Pédale pas incluse.  
Treadle and mounting brackets not included.

**Dual Circuit Foot Valve**

**E-12**




**FB065313X**

(Orifices 3/8" PT)  
(all ports 3/8" PT)

Pédale pas incluse.  
Treadle and mounting brackets not included.

**Dual Circuit Foot Valve**

**E-14**



**FB065314X**

Exh. port not threaded

**FB065317X**

Exh. port threaded 1/2" PT


**FB065395X**

Utilisé avec "manifold"  
Used with manifold

Pédale pas incluse.  
Treadle and mounting brackets not included.

## TP-2


### Tractor Protection



No. Pièce Part No.	Remorque Emer. Trailer Emer.	Remorque Svc. Trailer Svc.
FB227661X	A 3/8" PT	B 3/8" PT
FB227672X	A 1/2" PT	B 1/2" PT

### Tractor Protection

## TP-3




No. Pièces Part No.	Remorque Emer. Trailer Emer.	Remorque Svc. Trailer Svc.
* FS279000N	A 1/2" PT	B 1/2" PT
FB279692X	A 3/8" PT	B 3/8" PT

\* Disponible neuve seulement.  
As we are no longer rebuilding this valve, it is available "new" only.

## TP-3DC


### Tractor Protection



**FB5001455X**

### Tractor Protection

## TP-4




\* Exclusivement pour les tracteur Ford modèle "L".  
\* Exclusively for Ford "L" model tractors.

**FB288301X**

Précédemment une soupape à control VM-1  
Formerly VM-1 control valve

## Tractor Protection

**TP-5**



**FB106941X (Mack)**


**FB288605X**

**FB289253X** quand TC-2 n'est pas attaché  
when TC-2 is not connected.

Précédemment une soupape à control VM-2  
Formerly VM-2 control valve

## Pressure Protection

**PR-2**




No. pièce Part No.	Pression de fermeture Nominal Closing Pressure
FS277147N	65 PSI
FS277148N	85 PSI

Disponible neuve seulement.  
As we are no longer rebuilding this valve, it is available "new" only.

## Pressure Protection

**PR-3**

**PR-4**



No. pièce Part No.	PR	Pression de fermeture Nominal Closing Pressure
FB103976X	-4	45 PSI * voir/see note 1
FS286460N	-3	60 PSI * voir/see note 2, 3
FS286500N	-4	85 PSI * voir/see note 3
FB288323X	-4	70 PSI

\*2 Cette soupape est utilisé avec FB101112X & FB101622X  
This valve is used with FB101112X & FB101622X

\*3 Disponible neuve seulement.  
As we are no longer rebuilding this valve, it is available "new" only.


\*1 -Ce numéro de pièce est fabriqué pour l'usage avec les "aftercoolers" et les "air dryers" ou l'arrivée du turbocompresseur est turbocompressé.  
-This part number is designed for use with aftercoolers and air dryers where the air compressor turbocharger inlet is turbocharged.

## RV-1

### Pressure Reducing

# FB277144X


Pression adjustable  
Pressure setting is adjustable



## SS-1

### Shut Off Valve

# FB278824X




## SV-1

### Synchronizing Valve


No. pièce Part No.	Inlet Opens	Exhaust Opens
* FS278825N	42	28
FB281262X	75	60
FB283700X (with 222797 breather valve in exhaust port)	62	50

\* Disponible neuve seulement.  
As we are no longer rebuilding this  
valve, it is available "new" only.



**Double Check Valve,  
& Stop Light Switch**

**DS-1**




No. pièce Part No.	A	B	C	D
FB228520X	1/2	3/8	--	1/4
FB229493X	1/2	1/4	1/4	1/4

Tous les filets sont NPT  
All threads are NPT

**TR-2**


**Inversion Valve**



**FB277340X**

**Inversion Valve**

**TR-3**




No. pièce Part No.	Arrivé ouvert à Inlet opens at	Echappement ouvert à Exhaust opens at
FB101450X	25 PSI	40 PSI
FB280758X	45 PSI	60 PSI
FB281318X	35 PSI	70 PSI
FB281459X	25 PSI	40 PSI
FB288586X	75 PSI	90 PSI



## R-6

### Relay Valve




Nominal Pressure Differential 2 PSI

No. pièce Part No.	Espace des trous Bracket spacing	"F" PT
* FS279180N	2 1/2"	-
FB279952X	2 1/2"	3/4"
* FS283940N	5" (Ford)	-

- \* Disponible neuve seulement.  
As we are no longer rebuilding this  
valve, it is available "new" only.

### Modulating Valve

## R-7




## FS103081N

Disponible neuve seulement.  
As we are no longer rebuilding this  
valve, it is available "new" only.

Spring Brake Rel. Press. 95 PSI

## R-8

### Relay Valve



Orifice du "Bal." est sous le couvercle.  
Balance port is located under the cover.


Spring Brake Rel. Press. 95 PSI

## FS286370N

Disponible neuve seulement.  
As we are no longer rebuilding this  
valve, it is available "new" only.

### Pressure Equalizing Relay Valve


## R-8P



## FB287114X

**Relay Valve**

**R-12**



**FS065104N**

Del. 3/8" PT, Crack @ 4.0 PSI  
Disponible neuve seulement.  
As we are no longer rebuilding this valve, it is available "new" only.


**FS102626N**

Del. 1/2" PT, Crack @ 4.0 PSI  
Disponible neuve seulement.  
As we are no longer rebuilding this valve, it is available "new" only.

\* Les 4 orifices de sortie sont verticales / 4 Vertical delivery ports

**Relay Valve**

**R-12**




**FB065206X**

\* 4 orifices de sortie, 2 verticales et 2 horizontales  
\* 4 delivery ports, 2 Vertical, and 2 Horizontal

**Relay Valve**

**R-12H**



**FB065125X**

Sup. 1/2" PT, Crack @ 5.5 PSI

**FS103009N**

Sup. 3/4" PT, Crack @ 4.0 PSI  
Disponible neuve seulement.  
As we are no longer rebuilding this valve, it is available "new" only.

\* Les 2 orifices de sortie sont horizontales  
\* 2 Horizontal delivery ports

## R-12P

### Pilot Relay Valve

**FB109264X**

**\* Remplacer par  
Replaced by  
FS065476N**

Disponible neuve seulement.  
As we are no longer rebuilding this  
valve, it is available "new" only.



- \* 4 orifices de sortie, 2 verticales et 2 horizontales
- \* 4 delivery ports, 2 Vertical, and 2 Horizontal

## R-14


### Relay Valve

**FS103028N**

Crack @ 4.0 PSI  
Disponible neuve seulement.  
As we are no longer rebuilding this  
valve, it is available "new" only.

Orifice du "Bal." est sous le couvercle.  
Balance port is located under the cover.

- \* Les 4 orifices de sortie sont verticales
- \* 4 Vertical delivery ports



## R-14H


### Relay Valve

**FS103010N**

Crack @ 4.0 PSI  
Disponible neuve seulement.  
As we are no longer rebuilding this  
valve, it is available "new" only.

Orifice du "Bal." est sous le couvercle.  
Balance port is located under the cover.


- \* Les 2 orifices de sortie sont Horizontales
- \* 2 Horizontal delivery ports



Relay Emergency

**RE-4**


**FB229434X**



Relay Emergency

**RE-6**

**RE-6NC**



No. pièce Part No.	"C" PT	Soupape Valve
FB281860X	1/4"	RE-6
FS281865N	3/8"	RE-6
FB065451X	3/8"	RE-6NC

\* Disponible neuve seulement.  
As we are no longer rebuilding this  
valve, it is available "new" only.

## SR-1

### Spring Brake Valve

# FS286364N


Disponible neuve seulement.  
As we are no longer rebuilding this  
valve, it is available "new" only.

Res. #1  
1/4" PT

Cont.  
1/4" PT

Del.  
1/4" PT

Sup.  
1/4" PT



## SR-2

### Spring Brake Valve

No. pièce Part No.	Res. "A"	"Anti-Compounding"
FB288497X	1/2" PT	Non / No
FB103061X	1/2" PT	Oui / Yes
FB287376X	3/4" PT	Non / No
FB102761X	3/4" PT	Oui / Yes



Res.  
"A"

## SR-5

### Spring Brake Valve

No. pièce Part No.	Res. "A"	"Anti-Compounding"
* FS065437N	3/4" PT	Oui / Yes
FB065438X	3/4" PT	Non / No
* FS065439N	1/2" PT	Oui / Yes
FB065440X	1/2" PT	Non / No


\* Disponible neuve seulement.  
As we are no longer rebuilding this  
valve, it is available "new" only.



Res.  
"A"

## Spring Brake Valve

**SR-4**



PR-3 Valve  
BW286460X

Res.  
"A"

No. pièce Part No.	Res. "A"
FB101112X	3/4" PT
FB101622X	1/2" PT

Vieux modèle / Older Model

Nouveau modèle / Newer Model



Res.  
"A"

No. pièce Part No.	Res. "A"
FB107539X	3/4" PT
FB108076X	1/2" PT

## DV-2

### Automatic Drain Valve

#### FS281923N

Disponible neuve seulement.  
As we are no longer rebuilding this  
valve, it is available "new" only.

Sans élément chauffant  
Without heating element



Tous les orifices (2) 3/8" PT  
All ports (2) 3/8" PT

## DV-2

### Automatic Drain Valve

#### FS284412N 12 Volt

Disponible neuve seulement.  
As we are no longer rebuilding this  
valve, it is available "new" only.

#### FB284818X 24 Volt

Avec élément chauffant  
With heating element



Tous les orifices (2) 3/8" PT  
All ports (2) 3/8" PT

## DC-4

### Double Check Valve

#### FS278614N

Disponible neuve seulement.  
As we are no longer rebuilding this  
valve, it is available "new" only.



Tous les orifices (3) 3/8" PT  
All ports (3) 3/8" PT



**Assécheur d'air / Air Dryer**

**AD-IP**



Assécheur d'air complet  
Complete Air Dryer  
FB109477X 12V  
FB109478X 24V



Thermostat kit  
FS109495N



Safety Valve  
FS800350N



Purge Valve  
FB800404X



Cartouche / Cartridge  
FB109493X

**Gouverneur / Governor**

**D-2**



**FS284358N**

**Haute température,  
et imperméable**

**High Temperature  
and Waterproof**

Disponible neuve seulement.  
As we are no longer rebuilding this  
valve, it is available "new" only.



**AD-2**

**Assécheur d'air / Air Dryer**



Assécheur d'air complet  
Complete Air Dryer  
FB286934X 12 V  
FB286936X 24 V



Couvercle / Cover  
FB286875X 12 V  
FB286876X 24 V



Purge Valve  
FB286873X


Cartouche  
Cartridge  
FB101900X

**Accessoires / Accessories**

Safety Valve  
FS205105N



Thermostat Kit  
FS102657N




Purge Valve Kit  
FS787053N



Exhaust Adaptor  
AD-200

Remplacement d'adaptateurs d'échappement sont disponible pour les assécheurs d'air de Bendix et peut être réparé facilement et rapidement par le chauffeur. Trousse et instructions sont inclus.

Replacement exhaust adaptors are available for Bendix air dryers and can be easily and quickly repaired by the driver. Includes installation kit and instructions.



## Assécheur d'air / Air Dryer

**AD-4**



Assécheur d'air complet  
Complete Air Dryer  
FB065041X 12 V  
FB065040X 24 V



Couvercle / Cover  
FB065044X 12 V  
FB065043X 24 V



Cartouche  
Cartridge  
FB104358X

## Accessoires / Accessories

Safety Valve  
FS-11033



Thermostat Kit  
FS102657N




Purge Kit  
FS103818N



Exhaust Adaptor  
AD-400

Remplacement d'adaptateurs d'échappement sont disponible pour les assécheurs d'air de Bendix et peut être réparé facilement et rapidement par le chauffeur. Trousse et instructions sont inclus.

Replacement exhaust adaptors are available for Bendix air dryers and can be easily and quickly repaired by the driver. Includes installation kit and instructions.



**AD-9**

**Assécheur d'air / Air Dryer**



Assécheur d'air complet

Complete Air Dryer

FB109685X 12 V

FB065224X 24 V

FB109685HX for Holset  
compressor

FB065228X Extended  
Purge



Couvercle / Cover

FB065231X 12 V

FB065229X 24 V



Purge Valve Ass'y

FB5004341X 12 V

FB5004342X 24 V



Cartouche  
Cartridge  
FB107794X



Prise électrique  
Connector  
FS109869N



Check Valve Ass'y  
FB107800X

Accessoires / Accessories

Safety Valve

FS-11033



Thermostat Kit

FS109578N



Purge Valve Kit

FS107798N



Exhaust Cover

FS112399N



## Hi-Flow Relay Valve

### B12343X

(Remplace / Replaces  
B12345X)

- (1) 3/8" PT Svc.
- (4) 3/8" PT Del.
- (1) 3/4" PT Sup.

### B12347X

- (1) 3/8" PT Svc.
- (2) 3/8" PT Del.
- (1) 3/4" PT Sup.



## Task Valve

### B12360X

Avec / With Anti-Compound

- \* Avec orifice et écrou  
With port and nut

### B12361X

Sans / Without Anti-Compound

- \* Sans orifice (et écrou)  
Without port (and nut)

- (2) 1/4" PT Svc.
- (1) 1/4" PT Emer.
- (1) 3/4" PT Sup.
- (4) 3/8" PT Del.
- \* (1) 1/4" PT Anti-compound




Contrôle les "springbrakes" sur une remorque avec un ou deux essieux  
Controls springbrakes on single or dual axle trailers

## Relay Valve



### B12350X

4 Del. ports



- (1) 3/4" PT Sup.
- (1) 1/4" PT Svc.
- (1) 1/4" PT Emer.
- (4) 3/8" PT Del.

"A" Sans filet / Unthreaded  
"B" Sans trou / Without Hole  
"C" Avec filets / Threaded

Pour les remorques sans "spring brakes"  
For trailers without spring brakes

## SERV


### Serv Valve

(Service Emergency Relay Valve)



### B12352X

2 Del. ports



- (1) 1/4" PT Svc.
- (1) 3/4" PT Sup.
- (1) 1/4" PT Emer.
- (2) 3/8" PT Del.
- (1) 3/8" PT Spring brake

"A" Avec Filets / Threaded  
"B" Avec Trou / With Hole  
"C" Sans filet / Unthreaded

## Aftercooler




F7101X	Modèle / Model 62 (18 1/2")
F7103X	Modèle / Model 68 (23 1/2")
F7129NAX	Couvercle du bas (avec élément chauffant) Bottom Cap (with heating element)
F7129NASX	Couvercle du bas (sans élément chauffant) Bottom Cap (without heating element)

**Transmission Shift Valve**



**FA3546X**

**Transmission Control Valve**



**\* FA3547X  
FA4688X**

**\* Sortie sur le dessus  
\* Outlet on top**

*Coming  
soon*



**Transmission Control Valve**



**KH5468X**

**Transmission Control Valve**



**KH5470X**

## Quick Release, with two-way check


No. pièce Part No.	Del.
FKN32040X	1/4"
FKN32041X	3/8"



Contient une soupape d'échappement rapide avec un "2-way" check valve.  
Contains a quick release valve with a two-way check valve.

## Relay Valve

### RG-2



A fast, low crack pressure straight relay for Tractor-Trailer and Truck applications.  
Crack @ 6.0 PSI

No. pièce Part No.	Res. PT		Del. PT		Remarks
	A	B	C	D	
* FSKN28500N	3/8"	3/8"	3/8"	3/8"	Incl. (1) 3/8" plug
* FSKN28510N	3/8"	1/2"	3/8"	3/8"	Incl. (1) 1/2", (1) 3/8" plug
* FSKN28520N	1/2"	1/2"	1/2"	1/2"	Incl. (1) 1/2" plug
FKN28531X	1/2"	3/8"	3/8"	3/8"	

\* Disponible neuve seulement.

As we are no longer rebuilding this valve, it is available "new" only.

**FF-2**

**Full-Function Trailer Valve**



**FKN28600X**

Reservoir	3/4" PT
Control	1/4" PT
Supply	3/8" PT
Spring Brake(2)	3/8" PT
Service Brake(4)	3/8" PT

**FKN28601X**

Reservoir	1/2" PT
Control	1/4" PT
Supply	3/8" PT
Spring Brake(2)	3/8" PT
Service Brake(4)	3/8" PT

Crack @ 3 PSI

## Manifold Dash Module


No. pièce Part No.	Trous d'attachement Mounting Holes
FKN20601X	M6x1-6H Nuts
FKN20606X	1/4-20 UNC-2B
FKN20612X	10-24 UNC-2B
FKN20615X	Sans filet Unthreaded



Tous les orifices sont 1/4" PT  
All ports are 1/4" PT

## Double Flipper

No. pièce Part No.	Operation
FKN20080X	Manivelle à 3 position / 3 Handle Positions Centre (point mort), Debrayage manuel les 2 directions Neutral center, Manual release in both directions
FKN20090X	Manivelle à 3 position / 3 Handle Positions Centre (point mort), Debrayage automatique 1 direction, debrayage manuel à l'autre Neutral Center, Automatic release in one direction, manual release in the other
FKN20110X	Manivelle à 2 position / 2 Handle Positions Debrayage manuel sur les 2 directions Manual release in both directions



## Trailer Brake Control



No. pièce Part No.	Type	Del. PT	Sup.- PT	Exh.- PT
FKN20541X	Holding	1/4"	1/4"	1/4"
FKN20551X	Holding	3/8"	3/8"	1/8"
FKN20552X	Self-Releasing	3/8"	3/8"	1/8"

Manivelle tourner 72° maximum  
Handle rotates 72° maximum

\* Manivelle pas incluse  
Handle not Included

## Trailer Brake Control



### FKN20561X

Holding Type

### FKN20562X

Self-Releasing Type

Tous les orifices 1/4" PT  
All ports 1/4" PT

Installer à l'extérieur de la colonne de conduite.  
External steering column mount.

\* Manivelle pas incluse  
Handle not Included

Manivelle tourne 70° maximum.  
Handle rotates 70° maximum.

Côntrole à main / Hand Operated

### Single Circuit Foot Valve

**FKN22100X**



Pédale pas incluse.  
Treadle and mounting brackets not included.

### Dual Circuit Foot Valve

**FKN22140X**




Tous les orifices 3/8" PT  
all ports 3/8" PT

Pédale pas incluse.  
Treadle and mounting brackets not included.

## RG-5

### Relay Valve

(2 Orifice Del. / 2 Del. Ports )



No. pièce Part No.	Res. PT		Del. PT		Exhaust Excluder
	A	B	C	D	
FKN28550X	1/2"	X	3/8"	3/8"	Yes/Oui
FKN28551X	X	3/8"	3/8"	3/8"	Yes/Oui

X = bouché / plugged

Crack @ 6.0 PSI

### Relay Valve


(2 Orifice Del. / 2 Del. Ports )



No. pièce Part No.	Res. PT		Del. PT		Cont. PT	Crack PSI
	A	B	C	D		
FSKN28060N	1/2"	1/2"	3/8"	3/8"	3/8"	4.6
FKN28061X	1/2"	1/2"	1/2"	1/2"	3/8"	4.6
FKN28132X	1/2"	1/2"	1/2"	1/2"	3/8"	7.0

### Relay Valve

(4 Orifice Del. / 4 Del. Ports )




## FKN28080X

Crack @ 7.0 PSI

### Relay Valve

Frame Mounted, GM Style




## FKN28130X

Crack @ 4.6 PSI

## Relay Valve (2 Orifices Del. / 2 Del. Ports)

**FKN28065X**




Crack @ 4.6 PSI

## Relay Valve (2 Orifices Del. / 2 Del. Ports)

No. pièce Part No.	Sup.		Del.		Cont.	
	A PT	B PT	C PT	D PT	#1 - From Park Cont. Valve	#2 - From Rear axle Serv. Brake
FKN28070X	----	----	---->	USE	FKN28071X	<-----
FKN28071X	1/2"	X	1/2"	1/2"	1/4" PT	1/8 or 1/4
FKN28140X	-	1/2"	1/2"	1/2"	1/4" PT	-

FKN28071X features built-in anti-compounding between control #1 and #2



X = bouché / plugged


Crack @ 4.6 PSI

## Emergency Relay Valve (4 Orifices Del. / 4 Del. Ports)

No. pièce Part No.	Svc. PT	Emer. PT	Del.(4) PT	Aux. Res.	Res. PT
*FKN30200X	3/8"	3/8"	3/8"	1/2"	X
FKN30300X	1/4"	1/4"	1/4"	X	3/4"
FKN30400X	1/4"	1/4"	3/8"	X	3/4"

\* = NON-CHARGING

X = bouché / plugged




Crack @ 4.5 PSI



## RT-4

### Multifunction Trailer Valve




\*\* FKN26000X "Trailer cont." over Res. "A". FKN26010X "Trailer cont." over Res. "B"

No. pièce Part No.	Sup. PT		** Trailer Cont.	Res. PT		Del. PT	PPV Closing Pressure
	A	B		A	B		
FKN26000X	3/8"	3/8"	3/8"	1/2"	3/8"	(4) 3/8"	55 PSI
FKN26010X	3/8"	X	3/8"	1/2"	3/8"	(4) 3/8"	70 PSI

X = bouché / plugged

### Inversion Valve




## FKN28030X

Tous les orifices 1/4" PT  
All ports 1/4" PT

**Tractor Protection Valve**


**FKN34050X**



3 Ligne automatique avec échappement rapide  
3 Line Automatic, with Quick Release

**Tractor Protection Valve**


**FKN34060X**



2 Ligne avec échappement rapide  
2 Line with Quick Release

**Tractor Protection Valve**

**FKN34070X**



3 Ligne Automatique  
3 Line Automatic

## Pressure Protection Valve

Avec retenue à sens unique / with one way check




**\* FKN31010X**

Tous les orifices (2) 1/4" PT  
All ports (2) 1/4" PT


**\* Remplacer par FS-6596N**  
**Replaced by**

## Tractor Protection Valve

Pas automatique, type "manifold" / Manifold style, non-automatic



tractor protection, two double check valves,  
stoplight switch port, and quick release.




No. pièce Part No.	Note	Orifices (tous PT) / Ports (all PT)						
		A	B	C	D	E	F	H
FKN34080X	Véhicules Ford Vehicle	3/8"	3/8"	1/4"	3/8"	3/8"	3/8"	3/8"
FKN34090X	Véhicules Navistar Vehicle	3/8"	3/8"	1/4"	3/8"	1/2"	1/2"	3/8"
FKN34100X	Véhicules Ford Vehicle	3/8"	3/8"	1/4"	X	3/8"	3/8"	3/8"
FKN34110X	Véhicules Navistar Vehicle	3/8"	3/8"	1/4"	X	1/2"	1/2"	3/8"

**“Pure Air” Dryer****FKN33000X 12 Volt**

Peut-être monté verticale ou horizontale  
May be mounted vertically or Horizontally


Démontable par les deux côtés  
Serviceable from either end

## Spring Brake Control Valve



No. pièce Part No.	F110170X	F110310X	F110315X
Res. A	1/2" PT	3/8" PT	1/2" PT
Res. B	1/2" PT	1/2" PT	3/8" PT

## Mini Valve




Peut être remplacé par Sealco F110570X  
Can be replaced by Sealco F110570X

# F3100X


Crack @ 2.5 PSI

## Spring Brake Control Valve



No. pièce Part No.	F110171X	F110191X
Res. A	1/2" PT	3/8" PT
Res. B	3/8" PT	1/2" PT

## Spring Brake Control Valve




# F110147X

avec raccord 616  
with 616 nipple

# F110148X

## Charging Relay Emergency Valve




Pour remorque seulement.  
For trailer applications only.

Crack @ 4.5 PSI

No. pièce Part No.	"S" Sup. (1)	"C" Cont. (2)	"R" Res. (1)	"D" Del. (4)
Soupape d'urgence de relais à ratio / Ratio Relay Emergency Valve				
F110200X	1/4" PT	1/4" PT	3/4" PT	3/8" PT
F110205X	3/8" PT	3/8" PT	3/4" PT	3/8" PT
Soupape d'urgence de relais / Relay Emergency Valve				
F110470X	3/8" PT	3/8" PT	3/4" PT	3/8" PT


## Charging Relay Emergency Valve



Crack @ 4.5 PSI

No. pièce Part No.	"S" Sup. (1)	"C" Cont. (2)	"R" Res. (1)	"D" Del. (4)	"R2" Sup. Out. (1)
Avec 2 orifice réservoir / With 2 Reservoir ports					
F110475X	3/8" PT	3/8" PT	3/4" PT	3/8" PT	3/8" PT

## Non-Charging Relay Emergency Valve




Crack @ 4.5 PSI

No. pièce Part No.	"E" Emer. Sup. (1)	"C" Cont. (2)	"R" Res. (1)	"D" Del. (4)	"R2" Sup. Out (1)
F110338X	3/8" PT	3/8" PT	3/4" PT	3/8" PT	3/8" PT

### Relay Emergency Valve

**FA1000SX**



**FA1000-5AX**

Cartridge/Cartouche

Crack @ 1.5 PSI

### Service Relay Valve

2 port del.




**F110197X**

Crack @ 4.0 PSI

### Service Relay Valve

3 port del.



**F9125X**

Control 1/4" PT


**F110207X**

Control 3/8" PT

Crack @ 5.5 PSI

### Service Relay Valve

4 port del.




**F110139X**

**F110450X**

Crack @ 4.5 PSI

### Service Relay Valve


Remplace Midland RG-2 sans changer la tuyauterie  
Replaces Midland RG-2 without plumbing change



**F110360X (LOV-2)** Crack @ 1.5 PSI  
**F110410X** Crack @ 4.0 PSI


### Service Relay Valve

Remplace Bendix R-12 sans changer la tuyauterie  
Replaces Bendix R-12 without plumbing change



**F110380X (LOV-4)** Crack @ 1.5 PSI  
**F110415X** Crack @ 4.0 PSI


### Control Line Valve Dollies & Turnable Axles



**F110570X**

Crack @ 0 PSI

### Control Line Valve Trailers




**F110580X**

Crack @ 0 PSI




### Spring Brake Priority Valve

**F110500X**



### Spring Brake Exhaust Valve

**F3800X**




### Service Reservoir Priority System

**FS110800N**


- \* Avec trou / With hole  
Disponible neuve seulement.  
As we are no longer rebuilding this  
valve, it is available "new" only.

**F110700X**

- \* Sans trou / Without hole  
Remplacé avec / Replaced by  
**FS110800N**



## Air-electric Valve



**SH12387X**

**ABS**

**Truck, Tractor & Bus ABS**



**4725001030X**

Entire Valve Package  
(Use with C, D & E  
version ECU's)



**9730110220X**

Relay Valve



**4721950820X**

Modulator Valve



**4721950050X**

Modulator Valve  
(not for use with  
ABS valve package)



**4721950830X**

Modulator Valve

## ABS

### Trailer ABS

**xS** = Wheel-end Sensors  
**xM** = Modulator Valves



**4005001010X**  
ECU / Modulator  
Valve assembly  
**2S/1M**



**4721950330X**  
Modulator Valve only,  
part of 4005001010



**4005001030X**  
ECU / Modulator  
Valve assembly  
**2S/2M 4S/2M**  
**4S/3M "Premium"**



**4005001020X**  
ECU / Modulator  
Valve assembly  
**2S/2M "Standard"**



**4725000210X**  
ECU / Modulator  
Valve assembly  
**2S/1M**  
**(with 2 sensor ports)**



**4725000120X**  
ECU / Modulator  
Valve assembly  
**2S/2M 4S/2M**  
**(with 4 sensor ports)**


Plusieur combinaisons ECU / Modulateur disponible.

Appèlez avec votre numero de pièce.

Many ECU / Modulator combinations available. Phone with your Tag number.

## RF

### Relay Valve




**WA103600X**

Crack @ 3.0 PSI


### Trailer Valve

Contrôle les freins à ressort / Spring Brake Control



No. pièce Part No.	Res. PT		Sup. PT	Cont. PT	Del. PT	Anti-Compounding
	A	B				
WA88802X	1/2"	3/8"	3/8"	3/8"	3/8"	Oui / Yes
WA88812X	1/2"	3/8"	1/4"	X	3/8"	Non / No


## RG-4



**WA85490X**

### Trailer Valve

Contrôle les freins à ressort / Spring Brake Control



Part No. No. Pièce	Res. PT		Sup. PT		Cont. PT	Del. PT	Anti-Compounding
	A	B	C	D			
WA98730X	1/2"	3/8"	3/8"	3/8"	3/8"	3/8"	Oui / Yes
WA99370X	1/2"	3/8"	3/8"	X	3/8"	3/8"	Non / No